

## Stealth mouse button codes mapping

	15	13
	7	5
	11	9

16	14	
8	6	
12	10	



\* Buttons marked by green and red do not return its own codes but alters codes for buttons 7,5,8,6. Thus button 7 returns 11 when green button is pressed at the same time and returns 15 when red button is pressed.

IBox32.ini can be used to assign DPS “Delta” command for every button of stealth mouse.

### Available commands are:

- 1 Register
- 2 Zoom In
- 3 Zoom Out
- 4 Navigate
- 5 Autoregistration
- 6 Delete point
- 7 Snap to point
- 8 Snap to line
- 9 Snap to intersection
- 10 Snap to perpendicular
- 11 Close object
- 12 Finish object
- 13 Insert Break
- 14 Insert Arc
- 15 Autoscrolling
- 16 Select object
- 17 Delete objects
- 18 Lighter raster
- 19 Darker raster
- 20 2D/3D snap
- 21 Lock mouse
- 22 Exit capture mode

### Default settings are:

- Button1=1  
Button2=16  
Button3=4  
Button4=15  
Button5=11  
Button6=6  
Button7=5  
Button8=12  
Button9=9  
Button10=10  
Button11=7  
Button12=8  
Button13=2  
Button14=18  
Button15=3  
Button16=19

**Navigate** and **Autoscrolling** commands work until button is holding pressed.

**Navigate** command changes zoom temporary (while button is pressed) to move cursor to distant position of photo.

**Autoscrolling** command keeps constant cursor scrolling/moving (while button is pressed) using the last movement direction.